



ORIGINAL

CARBURETTOR AND COMPONENT PARTS

PRICE LIST

All prices in U. S. Dollars

Prices are subject to change due to unstable currencies



TILLOTSON LTD, CLASH INDUSTRIAL ESTATE, TRALEE, CO. KERRY, IRELAND

Tel: +353 66 7162500 Fax: +353 66 7124503 email: sales@tillotson.ie

www.tillotson.ie



MODEL	LIST PRICE	MODEL	LIST PRICE	MODEL	LIST PRICE	MODEL	LIST PRICE
HE SERIES		HL - 281A	108.86	HS - 115A	69.87	HS - 250A	82.70
HE - 1A	87.16	HL - 283A	108.86	HS - 118B	60.95	HS - 252A	82.70
HE - 5A	87.16	HL - 292G/D	84.96	HS - 121A	70.70	HS - 254A/B	82.70
HE - 6A	83.86	HL - 299G	90.47	HS - 123A	70.80	HS - 255B	82.70
HE - 7A	83.86	HL - 304E-F-WX	93.19	HS - 125B	79.39	HS - 256A	82.70
HE - 8A	83.86	HL - 311A	96.93	HS - 128B	71.47	HS - 257A	76.15
HE - 9B/C	83.86	HL - 314G/F	93.19	HS - 135C	83.22	HS - 260A	82.70
HE - 12A	83.86	HL - 320B	106.60	HS - 136C	79.04	HS - 262A	92.56
HE-10A	99.01	HL - 321A	106.91	HS - 138B	69.10	HS - 262B	92.56
HE-11A	99.01	HL - 324A	91.03	HS - 142A	Use HS-179B	HS - 263A	27.74
HE-12A	99.01	HL - 327D	114.29	HS - 144D	83.43	HS - 265A	84.41
		HL - 329C	97.09	HS - 151B	81.87	HS - 266A	84.41
HR SERIES		HL - 334A/B/AB	114.09	HS - 157A	79.25	HS - 267A	83.20
HR - 181B	259.28	HL - 339A	104.64	HS - 158F	79.01	HS - 268A	79.21
HR - 191G	259.28	HL - 342A	1168.96	HS - 161A	70.53	HS - 269B	79.21
HR - 192A	259.28	HL - 348E	117.51	HS - 163A	67.81	HS - 271D	77.13
HR - 194A	259.28		(is available only through E.C BIRT)	HS - 168A	76.46	HS - 273A	80.24
HR - 196A	259.28	HL - 351A	120.95	HS - 172B	83.14	HS - 274E	79.16
HR - 197A	259.28	HL - 352A	81.10	HS - 175D/F/G/H	92.75	HS - 275A /B	79.15
HR - 198A	259.28	HL - 355A/B/C/D	121.37	HS - 175K/L/M/N	92.75	HS - 276A/B/C/D	79.20
		HL - 357A/B	78.74	HS - 176A	100.03	HS - 277A	79.16
HK SERIES		HL - 360A/B/C	97.22	HS - 179B	82.24	HS - 278G	92.75
HK - 5C	55.17	HL - 363A/B/C	92.83	HS - 181C	68.15	HS - 279A/B/C/D	87.93
HK - 13D	55.17	HL - 364A	104.34	HS - 182C	82.18	HS - 280A/B/C/D	79.04
HK - 15D/E	60.13	HL - 365A/B	92.83	HS - 184A	85.44	HS - 281A/B/C/D	79.00
HK - 16D	55.17	HL - 366A	93.79	HS - 186A	76.22	HS - 282A	79.04
HK - 27B	58.39	HL - 368A	93.79	HS - 185A	82.18	HS - 283B	92.57
HK - 28C	92.19	HL - 369A	91.05	HS - 187A	82.18	HS - 284C/D/E/F	92.53
HK - 38A	Use HE - 8A	HL - 370A	94.41	HS - 189A	70.97	HS - 285A	92.55
HK - 42B	Use HE - 5A	HL - 371A	121.70	HS - 195A	79.49	HS - 286A	92.55
		HL - 372A	110.67	HS - 202A	77.75	HS - 292A	92.55
HL SERIES		HL - 374A	121.70	HS - 203E	82.26	HS - 293A	92.55
HL - 117E	102.61	HL - 375A	103.17	HS - 205A	70.70	HS - 294A	92.55
HL - 141B	95.68	HL - 380A/B	117.83	HS - 212B	75.52	HS - 295A	92.55
HL - 166B/C	77.98	HL - 381A	105.70	HS - 213A	84.16	HS - 296A	92.55
HL - 172B	95.68	HL - 382A	105.70	HS - 215A	56.67	HS - 297A	92.55
HL - 173E	98.33	HL - 383A	80.96	HS - 216C	82.38	HS - 298A	94.27
HL - 176A	90.73	HL - 384A	99.53	HS - 218A	78.50	HS - 299A	92.33
HL - 189F	Use HL-173E	HL - 384B	99.53	HS - 219C	82.59	HS - 300A	94.59
HL - 220AX	101.19	HL - 385A	99.53	HS - 220A	73.07	HS - 301A	96.51
HL - 223A	81.36	HL - 386A	104.82	HS - 222B	81.92	HS - 304A	96.51
HL - 226A	86.60	HL - 388A	111.45	HS - 223A/B	68.81	HS - 307A	92.31
HL - 229F	107.03	HL - 390A	103.43	HS - 224A	73.57	HS - 309B	98.19
HL - 231E	121.37			HS - 225A	81.92	HS - 310A	92.37
HL - 232E/F	94.89	HS SERIES		HS - 226A	80.39	HS - 310C	98.04
HL - 239B	81.12	HS - 4D	70.55	HS - 228C	73.80	HS - 311A	92.96
HL - 256A	106.48	HS - 5C	78.68	HS - 230C/D	73.57	HS - 311C	98.04
HL - 257A	102.53	HS - 25B/C	78.10	HS - 232E	82.48	HS - 313A	92.96
HL - 261A	107.38	HS - 28D	70.70	HS - 234B	73.59	HS - 313C	98.04
HL - 266A	99.50	HS - 39B	66.45	HS - 235B	87.21	HS - 315A	101.67
HL - 268A	103.36	HS - 59A	78.42	HS - 236C/D/E	92.46	HS - 315B	105.58
HL - 274E	80.55	HS - 60D/E	80.66	HS - 237A	80.77	HS - 317A	95.16
		HS - 87A	79.04	HS - 238B	82.48	HT SERIES	
		HS - 101C	57.84	HS - 239A/B/C/D	92.55	HT - 5A	109.18
		HS - 110B	66.63	HS - 240C	77.67	HT - 7A	144.98
				HS - 241A	87.22		

MODEL	LIST PRICE	MODEL	LIST PRICE	PART NUMBER	BASIC USAGE	LIST PRICE
HT - 8A	104.79	HU - 103A	82.51	RK - 18HU		8.24
HT - 9A	104.82	HU - 105A	80.61	RK - 19HU		8.24
HT - 11B	141.96	HU - 106A	84.76	RK - 20HU		13.24
HT - 11D	149.06	HU - 107D	49.77	RK - 21HU		8.24
HT - 12B	104.82	HU - 108C	49.77	RK - 22HU		8.24
HT - 12C	144.76	HU - 112B	52.81	RK - 23HU		8.24
HT - 12D	147.33	HU - 113B	52.81			
HT - 12E	149.06	HU - 114B/D/E	51.27	RK - 18HS		8.95
HT - 13A	103.64	HU - 115B	52.81	RK - 19HS		8.95
HT - 14A	104.82	HU - 116B	92.55	RK - 20HS		8.95
HT - 15A	150.48	HU - 117B	52.81	RK - 21HS		8.95
HT - 18A	150.48	HU - 118A	49.77	RK - 23HS		8.95
HT - 20A	104.82	HU - 120A	62.92	RK - 24HS		8.95
				RK - 25HS		8.95
				RK - 26HS		8.95
				RK - 27HS		8.95
				RK - 28HS		8.95
				RK - 29HS		8.95
				RK - 30HS		8.95
				RK - 31HS		8.95
				RK - 32HS		8.95
				RK - 33HS		8.95
				RK - 34HS		8.95
				RK - 35HS		8.95
				RK - 1HT		8.92
				RK - 2HT		8.92
				RK - 3HT		8.92
				RK - 4HT		13.92
				RK - 1HE		10.16
HU SERIES		REPAIR KITS		DIAPHRAGM & GASKET SETS		
HU - 1C	92.28	RK - 32HK	10.22	DG - 1HK	HK	6.92
HU - 3G	71.17	RK - 33HK	10.22			
HU - 4B	92.33	RK - 34HK	10.22	DG - 1HL	HL	7.20
HU - 7A	84.19	RK - 35HK	10.22	DG - 4HL/R	HL/HR	8.11
HU - 10C	71.72	RK - 36HK	10.22	DG - 5HL	HL	7.20
HU - 19F	65.09	RK - 37HK	10.22			
HU - 21A	86.53			DG - 2HS/T	HS/HT	5.86
HU - 24C	65.09	RK - 82HL	13.34	DG - 3HS/T	HS/HT	5.86
HU - 26A	79.29	RK - 83HL	13.34	DG - 5HS/T	HS/HT	5.86
HU - 26B	82.47	RK - 84HL	12.96	DG - 7HS	HS	5.86
HU - 28A	85.86	RK - 86HL	12.96	DG - 8HS	HS	5.86
HU - 37A	78.10	RK - 88HL	13.34	DG - 9HS	HS	5.86
HU - 37C	70.62	RK - 90HL	13.34	DG - 10HS	HS	5.86
HU - 39B	79.04	RK - 92HL	13.34	DG-11HS	HS	5.86
HU - 40D	58.71	RK - 97HL	13.34	DG - 2HU	HU	5.69
HU - 51C	58.71	RK - 98HL	13.34	DG - 3HU	HU	5.69
HU - 52C	58.71	RK - 99HL	13.34	DG - 4HU	HU	5.69
HU - 54C	58.06	RK - 100HL	13.34	DG - 5HU	HU	5.69
HU - 54D	58.06	RK - 102HL	13.34	DG - 6HU	HU	5.69
HU - 57C	91.08	RK - 103HL-HR	13.34			
HU - 62B	75.40	RK - 104HL	15.01			
HU - 63B	61.63	RK - 105HL	13.34			
HU - 63C	61.63	RK - 106HL	13.34			
HU - 65C	63.91	RK - 107HL	13.34			
HU - 66A	73.25	RK - 111HL	13.34			
HU - 68A	66.06	RK - 112HL	18.76			
HU - 70A	88.40	RK - 113HL	15.30			
HU - 70B	67.46	RK - 114HL	15.30			
HU - 72A	81.84	RK - 115HL	13.34			
HU - 74A	71.96	RK - 116HL	13.34			
HU - 81A	72.39	RK - 117HL	13.34			
HU - 82B	92.91	RK - 118HL	13.34			
HU - 83E/F	85.07	RK - 119HL	22.88			
HU - 84E	67.60	RK - 120HL	13.34			
HU - 87A	72.73	RK - 121HL	16.88			
HU - 87B	72.73	RK - 14HU	8.24			
HU - 91A	92.27	RK - 15HU	8.24			
HU - 99C	52.17	RK - 16HU	8.24			
HU - 100B/D	66.76	RK - 17HU	8.24			
HU - 101B	90.05	RK - 18HU	8.24			



PART NO.	DESCRIPTION	LIST PRICE	PART NO.	LIST PRICE	USAGE	DESCRIPTION
SPECIAL KITS			THROTTLE LEVERS			
392 - 501	Use 392 - 502		12B-130	0.57	HL	Throttle Lever
392 - 502	Choke Valve Kit	7.64	12B-178	0.74	HS	Throttle Lever
392 - 504	Choke Valve Kit	7.64	12B-184	0.43	HS	Throttle Lever
392 - 505P	Choke Valve Kit	7.64	12B-221	2.38	HL	Throttle Lever
392 - 506P	Choke Valve Kit	7.64	12B-256	0.47	HK	Throttle Lever
392 - 508P	Choke Valve Kit	10.43				
392 - 510P	Choke Valve Kit	4.72	12B-259	0.48	HK	Throttle Lever
LEAK DETECTOR			12B-289	0.81	HK	Throttle & Choke Lever
243 - 504		84.15	12B-313	0.81	HK	Throttle Lever
FUEL PRIMERS			12B-322	0.72	HK	Throttle Lever
362 - 501		5.98	12B-363	0.93	HS	Throttle Lever
362 - 504		5.98	12B-392	0.50	HK	Throttle Lever
SERVICE VIDEO			12B-436	0.54	HS	Throttle Lever
V-VID	(Net Price)	26.00	12-1154	5.17	HL	Throttle Lever
CD ROM SERVICE MANUAL			12-1156	5.11	HS	Throttle Lever
CD-ROM	(Net Price)	10.40	12-1158	4.43	HS	Throttle Lever
FILTERS			12-1164	3.19	HS	Throttle Lever
	<u>Zinc body/felt element pro.</u>		12-1167	2.24	HL	Throttle Lever
OW - 497 - P	fuel line ID 3/16"	2.84	12-1180	7.37	HL	Throttle Lever
OW - 802 - P	fuel line ID 3/16"	2.34	12-1204	3.92	HL	Throttle Lever
OW - 497 - D		28.08	12-1205	3.72	HU	Throttle Lever
OW - 497 - Z		67.60	12-1208	2.49	HO	Throttle Bracket Linkage
OW - 802 - D		22.88	12-1212	6.08	FO/HO	Throttle Bracket Assembly
OW - 802 - L		104.00	12-1213	8.11	HR	Throttle Lever
	<u>Plastic body/porex element std.</u>		12-1216	7.06	HL	Throttle Lever Assembly
TP - 01 - P	fuel line 1/8" ID	2.08	THROTTLE SHAFTS			
TP - 02 - P	fuel line 3/16" ID	2.08	13-1569	8.65	HL	Shaft & Lever
	<u>Plastic body/porex element pro.</u>		13-1586	9.97	HL	Shaft & Lever
TP - 04 - P	fuel line 1/4" ID	3.08	13-1592	8.50	HL	Shaft & Lever
TP - 05 - P	fuel line 1/4" ID	3.02	13-1639	8.32	HL	Shaft & Lever
TP - 06 - P	fuel line 3/16" ID	3.02	13-1656	13.42	HL	Shaft & Lever
TP - 07 - P	fuel line 1/8" ID	3.02				
			13-1661	6.88	HS	Shaft & Lever
FS - 1 - P	fuel line 3/16" ID	11.24	13-1662	8.73	HS	Shaft & Lever
			13-1664	9.86	HS	Shaft & Lever
			13-1695	7.26	HS	Shaft & Lever
			13-1714	6.59	HO	Shaft & Lever
			13-1744	6.47	HU	Shaft & Lever
			13-1781	10.75	HS	Shaft & Lever
			13-1838	12.99	HS	Shaft & Lever
			13-1849	8.31	HS	Shaft & Lever
			13-1888	5.19	HK	Shaft & Lever
			13-1893	4.52	HS	Shaft & Lever
			13-1894	14.62	HL	Shaft & Lever
			13-1895	4.78	HS	Shaft & Lever
			13-1897	3.72	HS	Shaft & Lever
			13-1900	2.26	HU	Shaft & Lever
			13-1912	25.06	TC	Shaft & Lever
			13-1932	4.06	HS	Shaft & Lever
			13-1944	6.14	HS	Shaft & Lever



LIST				LIST				
PART NO.	PRICE	USAGE	DESCRIPTION	PART NO.	QTY CODE	PRICE	USAGE	DESCRIPTION
THROTTLE SHAFTS				13-2089		5.79	HU	Shaft & Lever
13-1950	5.08	HS	Shaft & Lever	13-2092		5.97	HU	Shaft & Lever
13-1951	3.42	HS	Shaft & Lever	13-2093		11.59	HS	Shaft & Lever
13-1956	4.23	HS	Shaft & Lever	13-2094		4.56	HU	Shaft & Lever
13-1974	7.77	HU	Shaft & Lever	13-2096		6.95	HS	Shaft & Lever
13-1975	6.41	HU	Shaft & Lever	13-2098		7.16	HU	Shaft & Lever
13-1986	6.45	HU	Shaft & Lever	13-2100		8.11	HS	Shaft & Lever
13-1988	6.45	HU	Shaft & Lever	13-2102		10.74	HL	Shaft & Lever
13-1991	8.67	HK	Shaft & Lever	13-2105		10.43	HL	Shaft & Lever
13-2011	4.04	HS	Shaft & Lever	13-2106		4.65	HU	Shaft & Lever
13-2012	5.92	HS	Shaft & Lever	13-2107		9.86	HS	Shaft & Lever
13-2021	17.18	HT	Shaft & Lever	13-2109		11.93	HS	Shaft & Lever
13-2022	5.40	HU	Shaft & Lever	13-2111		8.35	HS	Shaft & Lever
13-2023	7.97	HU	Shaft & Lever	13-2112		8.35	HS	Shaft & Lever
13-2024	11.69	HL	Shaft & Lever	13-2113		9.86	HS	Shaft & Lever
13-2025	11.06	HK	Shaft & Lever	13-2114		8.11	HE	Shaft & Lever
13-2026	4.57	HU	Shaft & Lever	13-2116		8.35	HS	Throttle Shaft
13-2027	3.29	HU	Shaft & Lever	13-2117		8.35	HS	Throttle Shaft
13-2028	5.77	HS	Shaft & Lever	13-2119		10.74	HL	Throttle Shaft
13-2030	3.65	HU	Shaft & Lever	13-2120		7.88	HS	Throttle Shaft
13-2031	3.99	HU	Shaft & Lever	13-2121		8.35	HU	Throttle Shaft
13-2033	10.81	HL	Shaft & Lever	13-2126		11.73	HS	Throttle Shaft
13-2037	3.22	HS	Shaft & Lever	13-2127		8.07	HS	Throttle Shaft
13-2038	6.84	HS	Shaft & Lever	13-2129		15.37	HS	Throttle Shaft
13-2040	4.98	HS	Shaft & Lever	13-2133		6.38	HU	Throttle Shaft
13-2041	13.84	HT	Shaft & Lever	13-2137		4.96		Throttle Shaft
13-2043	8.13	HS	Shaft & Lever	THROTTLE SHUTTERS				
13-2044	4.40	HU	Shaft & Lever	14A-1	X	0.66	HK	Shutter
13-2045	7.35	HU	Shaft & Lever	14A-2	X	1.09	HT	Shutter
13-2047	3.20	HU	Shaft & Lever	14A-4	X	0.63	HU	Shutter
13-2049	5.58	HS	Shaft & Lever	14A-6	X	0.63	HK	Shutter
13-2050	20.32	WB	Shaft & Lever	14A-7	X	0.63	HT	Shutter
13-2054	20.07	WB	Shaft & Lever	14A-9	Use 14A-34			
13-2055	20.46	WB	Shaft & Lever	14A-10	X	0.63	HS	Shutter
13-2058	7.49	HU	Shaft & Lever	14A-11	X	0.63	HO	Shutter
13-2061	6.05	HO	Shaft & Lever	14A-12	X	0.63	HS	Shutter
13-2062	8.07	HE	Shaft & Lever	14A-14	X	1.09	HT	Shutter
13-2065	11.00	HO	Shaft & Lever	14A-16	X	0.63	HU	Shutter
13-2066	10.35	FO	Shaft & Lever	14A-17	X	0.63	WB	Shutter
13-2069	3.87	HS	Shaft & Lever	14A-18	X	1.09	WB	Shutter
13-2070	20.90	WB	Shaft & Lever	14A-19	X	1.09	WB	Shutter
13-2080	5.97	HE	Shaft & Lever	14A-20	Use 14A-34			
13-2081	10.74	HL	Shaft & Lever	14A-23	X	0.63	HS	Shutter
13-2082	6.57	HU	Shaft & Lever	14A-26	X	0.63	HS	Shutter
13-2083	7.49	HU	Shaft & Lever	14A-27	X	1.09	FO	Shutter
13-2084	19.52	HR	Shaft & Lever	14A-31	X	1.09	TC	Shutter
13-2085	16.14	FO	Shaft & Lever	14A-32	X	1.09	HO	Shutter
13-2086	15.67	FO	Shaft & Lever					



PART NO.	QTY CODE	LIST PRICE	USAGE	DESCRIPTION	PART NO.	QTY CODE	LIST PRICE	USAGE	DESCRIPTION
THROTTLE SHUTTERS					15B-329	X	0.57	HL,HS	Screw
14A-34	X	0.63	HL	Shutter	15B-330	X	0.57	HS,HU	Screw
14A-38	X	1.09	TC	Shutter	15B-333	X	0.73	HS	Cover Screw
14A-42	X	1.09	HS	Shutter	15B-343	X	0.90	HL	Screw
14A-43	X	1.75	TC	Shutter	15B-345	X	0.57	HS	Screw
14A-44	X	0.55	HE	Shutter	15B-348	X	0.57	HS	Screw
14A-48	X	1.75	HR	Shutter	15B-353	X	0.57	HU	Screw & Lockwasher
14A-49	X	1.06	WB	Shutter	15B-367	X	1.03	HU	Idle Speed Screw
14A-52	X	1.09	HR	Shutter	15B-370	X	0.57	HK	Screw
14A-53	X	0.75	WB	Shutter	15B-371	X	0.57	HK	Screw
14A-54	X	1.46	HT	Shutter	15B-381	X	2.53	HK	Idle Speed Screw
14A-55	X	1.46	FO	Shutter	15B-401	X	1.81	HK	Idle Speed Screw
14A-58	X	1.09	HS	Shutter	15B-413	X	2.44	HS	Idle Speed Screw
14A-60	X	0.63	HT	Shutter	15B-414	Use 15C-20			
14A-61	X	1.09	HO	Shutter	15B-415	X	1.78	HS	Idle Speed Screw
14-386	X	0.66		Shutter	15B-416	X	0.55	HS	Screw
14-396	X	0.66	HL	Shutter	15B-417	X	0.57	HS	Screw
14-407	X	0.66	HL	Shutter	15B-441	X	2.87	HK	Idle Speed Screw
14-415	X	1.37	HR	Shutter	15B-468	X	1.63	HU	Idle Speed Screw
14-423	X	0.66	HK,HU	Shutter	15B-486	X	2.80	HK	Idle Speed Screw
14-430	X	0.66	HS	Shutter	15C-1	X	1.48	HU	Idle Speed Screw
14-431	X	0.66	HS	Shutter	15C-3	X	2.88	HK	Idle Speed Screw
14-432	X	0.66	HU	Shutter	15C-6	X	0.94	HE	Metering Cover Screw
14-442	X	1.12	HK,HU	Shutter	15C-9	X	1.47	HL	Idle Speed Screw
14-444	X	1.12	TC	Shutter	15C-14	X	0.94	HS	Idle Speed Screw
14-445	X	0.66	HS	Shutter	15C-18	X	0.57	HL	Screw
14-446	X	0.66	HU	Shutter	15C-19	X	0.57	HS	Diaphragm Cover Screw
14-453	X	0.66	HU	Shutter	15C-20	X	0.57	HS	Idle Speed Screw
14-457	X	1.12	HO	Shutter	15C-21	X	1.98	HS	Idle Speed Screw
14-458	X	0.66	HS	Shutter	15C-24	X	3.92	HT	Idle Speed Screw
14-465	X	0.66	HK	Shutter	15C-25	X	7.48	HT	Idle Speed Screw
14-471	X	0.66	HK,HS	Shutter	15C-29	X	2.44	HL	Screw
14-476	X	0.66	HS	Shutter	15C-30	X	0.57	HS	Screw
14-485	X	0.66	HK	Shutter	15C-33	X	0.48	TC	Sealing Screw
14-491	X	0.66	HK	Shutter	15C-34	X	1.20	HU	Swivel Screw
14-498	X	0.66	HK	Shutter	15C-38	X	3.21	FO	Screw
14-499	X	0.66	HU	Shutter	15C-43	X	2.82	HR	Screw
SCREWS					15C-44	X	1.76	HS	Screw
15B-282	X	0.57	HL	Screw	15C-45	X	0.57	HU	Screw
15B-285	X	0.57	M	Screw	15C-46	X	0.57	HS	Screw
15B-297	Use 15-C9		M	Screw	15C-50	X	0.75	HU	Screw
15B-300	X	0.57	M	Screw	15C-51	X	0.75	HL	Screw
15B-306	X	0.57	M	Screw & Lockwasher	15C-52	X	0.75	HL	Screw
15B-307	Use 15C-20				15C-53	X	0.75	HS	Metering Cover Screw
15B-313	X	0.57	HL	Screw	15C-54	X	0.75	HS	Metering Cover Screw
15B-318	X	0.57	HL	Screw	15C-55	X	3.22	HS	Screw
15B-321	X	0.57	HL	Screw & Lockwasher	15C-58	X	7.25	HS	Screw
15B-322	X	0.57	FS	Screw	15C-59	X	3.11	HS	Screw
15B-325	X	0.57	HL	Screw	15C-65	X	3.37	HU	Screw



PART NO.	QTY CODE	LIST PRICE	USAGE	DESCRIPTION	PART NO.	QTY CODE	LIST PRICE	USAGE	DESCRIPTION
GASKETS					24B-326	X	0.48	HS	Throttle Ret. Spring
16B-179	X	0.48	M	Gasket	24B-328	X	0.73	HK	Throttle Ret. Spring
16B-180	X	0.48	TC	Gasket	24B-331	X	0.49	HK,HS	Mixture Screw Spring
16B-184	X	0.48	HS	Gasket	24B-344	X	0.67	HL	Throttle Ret. Spring
16B-199	X	0.48	HL	Inlet Seat Gasket	24B-345	X	1.07	HS,HL	Inlet Tension Spring
16B-204	X	0.48	HL	Gasket	24B-355	Use 24C-263			
					24B-365	X	0.57	HS	Spring
16B-205	X	0.48	HL	Strainer Gasket	24B-368	X	0.57	HU	Inlet Tension Spring
16B-206	X	0.48	HL	Flange Gasket	24B-369	X	0.72	HK,HS,HU	Inlet Tension Spring
16B-212	X	0.48	HL	Strainer Gasket	24B-371	X	0.69	HS	Spring
16B-216	X	0.48	HL	Flange Gasket	24B-372	X	0.57	HK,HL	Inlet Tension Spring
16B-217	X	0.48	HL	Diaphragm Gasket	24B-374	X	0.72	HK,HS	Inlet Tension Spring
					24B-376	X	0.90	HU	Throttle Ret. Spring
16B-223	X	0.48	HL	Fuel Pump Gasket	24B-377	X	0.79	HU	Inlet Tension Spring
16B-225	X	0.48	HL	Gasket	24B-378	X	0.77	HS,HU	Inlet Tension Spring
16B-226	X	0.48	HS	Diaphragm Gasket	24B-381	X	0.82	HL	Throttle Ret. Spring
16B-227	X	0.48	HS	Fuel Pump Gasket	24B-397	X	0.80	HU	Throttle Ret. Spring
16B-228	X	0.48	HS	Flange Gasket	24B-404	X	1.02	TC	Throttle Ret. Spring
					24B-418	X	0.81	HK,HS	Inlet Tension Spring
16B-243	X	0.48	HS	Flange Gasket	24B-434	X	0.37	HS	Throttle Ret. Spring
16B-246	X	0.48	HU	Diaphragm Gasket	24B-435	X	0.32	HS	Throttle Return Spring
16B-247	X	0.48	HU	Fuel Pump Gasket	24B-437	X	0.77	HS	Throttle Return Spring
16B-248	X	0.48	HU	Flange Gasket	24B-444	X	0.81	HK	Throttle Return Spring
16B-249	X	0.48	HS	Flange Gasket	24B-447	X	0.77	HS	Throttle Return Spring
					24B-449	X	0.49	HS	Mixture Screw Spring
16B-252	X	0.48	HL	Gasket	24B-450	X	0.57	HS	Mixture Screw Spring
16B-253	X	0.48	HL	Inlet Valve Gasket	24B-474	X	0.93	HK	Throttle Return Spring
16B-272	X	0.48	HK	Fuel Pump Gasket	24C-15	X	0.78		
16B-273	X	0.48	HK	Diaphragm Gasket	24C-29	X	0.59	HS	Throttle Ret. Spring
16B-274	X	0.48	HK	Flange Gasket	24C-141	X	0.82	HS	Choke Ret. Spring
16B-275	X	0.48	HK	Module Gasket	24C-146	X	0.84	HU	Throttle Ret. Spring
16B-277	X	0.48	HK	Gasket	24C-219	X	0.68		
16B-279	X	0.48	HK	Module Gasket	24C-226	X	2.01	HT	Throttle Return Spring
16B-291	X	0.48	HL	Gasket	24C-228	X	0.60	HS	Choke Valve Spring
16B-294	X	0.48	HK	Module Gasket	24C-229	X	0.64	TC	Choke Ret. Spring
16B-295	X	0.48	HK	Module Gasket	24C-233	X	0.72	WB	Choke Return Spring
16B-314	X	0.48	HK	Module Gasket	24C-234	X	0.72	WB	Throttle Ret. Spring
16B-330	X	0.48	HL	Gasket	24C-239	X	1.11		
16B-352	X	0.48	HL	Fuel Pump Gasket	24C-235	X	0.72	WB	Throttle Return Spring
16B-376	X	0.48	HT	Flange Gasket	24C-244	X	0.72	WB	Throttle Return Spring
16B-378	X	0.48	HU	Flange Gasket	24C-246	X	1.08	FO	Throttle Return Spring
16B-383	X	0.48	HU	Diaphragm Gasket	24C-248	X	0.72	HU	Spring
16B-390	X	0.48	HS	Diaphragm Gasket	24C-250	X	1.31	HU	Spring
					24C-251	X	0.60	HS	Spring
					24C-252	X	0.60	HS	Spring
					24C-257	X	0.84	HU	Spring
					24C-259	X	0.83	HU	Spring
					24C-261	X	0.83	HU	Spring
					24C-262	X	0.83	HU	Spring
					24C-263		0.83	HU	Spring
					24C-264	X	1.10	HS	Spring
					24C-265		0.86	HS	Spring
					24C-266		0.86	HS	Spring
					24C-267		0.83	HS	Choke Return Spring
					24C-268		0.83	HT	Throttle Return Spring
					24C-269	X	1.08	HR	Spring
SPRINGS									
24B-131	X	0.41	HL	Mixture Screw Spring					
24B-247	X	0.49	HO	Idle Speed Reg. Spring					
24B-281	X	0.66	HE	Choke Friction Spring					
24B-289	X	0.71	HL	Inlet Tension Spring					
24B-291	X	0.49	HL	Throttle Ret. Spring					
24B-298	X	0.49	HS	Mixture Screw Spring					
24B-299	X	0.52	HL,HS	Inlet Tension Spring					
24B-305	X	0.82	HS	Throttle Ret. Spring					
24B-322	X	0.49	HS	Throttle Ret. Spring					
24B-323	X	0.61	HL	Inlet Tension Spring					



PART NO.	QTY CODE	LIST PRICE	USAGE	DESCRIPTION	PART NO.	QTY CODE	LIST PRICE	USAGE	DESCRIPTION
24C-270	X	0.83	HS	Spring	26-1266		6.17	HS	Choke Shaft
24C-272	X	0.83	HS	Spring	26-1268		12.48	HT	Choke Shaft & Lever
24C-273	X	0.83	HL	Spring	26-1271		3.85	HS	Choke Shaft & Lever
24C-274	X	0.83	HS	Spring	26-1272		4.70	HS	Choke Shaft & Lever
24C-275	X	0.83	HL	Spring	26-1274		4.70	HS	Choke Shaft & Lever
24C-276	X	1.00	HU	Spring	26-1279		5.17	HS	Choke Shaft & Lever
24C-279	X	1.31	HS	Spring	26-1280		4.60	HS	Choke Shaft & Lever
24C-280	X	1.31	HS	Spring	26-1282		5.80	HS	Choke Shaft & Lever
24C-281	X	1.31	HS	Spring	26-1283		18.06	TC	Choke Shaft & Lever
CHOKE LEVER					26-1288		5.16	HS	Choke Shaft & Lever
25-392		1.11	HL	Choke Lever	26-1290		16.14	FO	Choke Shaft & Lever
25-425		0.47	HS	Choke Lever	26-1291		8.07	HE	Choke Shaft & Lever
25-427		0.60	HS	Choke Lever	26-1292		7.82	HS	Choke Shaft & Lever
25-457		0.75	HS	Choke Lever	26-1298		5.16	HS	Choke Shaft & Lever
25-458		0.77	HK	Choke Lever	26-1300		5.22	HS	Choke Shaft
25-469		0.47	HS	Choke Lever	26-1301		5.22	HS	Choke Shaft
25-471		4.12	HT	Choke Lever	26-1304		5.39	HS	Choke Shaft
25-474		1.13	HS	Choke Valve Lever	26-1307		7.53	HS	Choke Shaft
25-497		0.64			26-1308		5.34	HS	Choke Shaft
25-498		6.19	HS	Idle Lever	26-1309		5.38	HS	Choke Shaft
25-696		2.86	HL	Choke Lever	26-1310		10.78	HS	Choke Shaft
CHOKE SHAFT					26-1311		5.32	HS	Choke Shaft
26A-194		6.97	HL	Choke Shaft	CHOKE SHUTTER				
26A-212		6.97	HS	Choke Shaft	27-289	X	3.42	TC	Choke Shutter
26A-215		6.97	HS	Choke Shaft	27-296	X	0.74	HL,HS	Shutter
26A-219		6.97	HS	Choke Shaft	27-308	X	1.29	HL,HS	Shutter
26-461		8.09	HL	Choke Shaft	27-309	X	0.93	HL,HS	Shutter
26-955		10.12	HL	Shaft & Lever	27-310	X	0.81	HS	Shutter
26-977		11.72	HL	Shaft & Lever	27-311	X	0.80	HL	Choke Shutter
26-1003		6.74	HS	Shaft & Lever	27-316	X	3.16	HL	Shutter
26-1012		14.66	HL	Shaft & Lever	27-320	X	0.69	HK,HS	Shutter
26-1013		9.29	HL	Choke Shaft	27-327	X	0.81	HO	Choke Shutter
26-1020		10.43	HL	Shaft & Lever	27-329	X	1.08	HS	Shutter
26-1036		10.98	HL	Shaft & Lever	27-331	X	0.69	HS	Shutter
26-1037		7.78	HS	Shaft & Lever	27-333	X	0.81	WB	Choke Shutter
26-1041		6.52	HS	Shaft & Lever	27-334	X	0.81	WB	Choke Relief Valve
26-1089		6.31	HO	Choke Shaft & Lever	27-342	X	0.88	HS	Shutter
26-1124		23.45	HS	Shaft & Pin Assembly	27-352	X	1.04	HK	Shutter
26-1135		6.50	HS	Shaft & Lever	27-360	X	0.92	HT	Choke Shutter
26-1139		9.15	HS	Shaft & Lever	27-361	X	0.81	HO	Choke Shutter
26-1193		4.36	HS	Choke Shaft & Lever	27-363	X	0.81	WB	Choke Shutter
26-1196		6.70	HK	Choke Shaft & Lever	27-365	X	0.86	FO	Choke Shutter
26-1212		5.55	HS	Choke Shaft & Lever	27-366	X	0.79	WB	Choke Shutter
26-1238		6.26	HS	Choke Shaft & Lever	27-369	X	0.76	HS	Choke Shutter
26-1239		4.51	HS	Choke Shaft & Lever	27-370	X	0.76	HS	Choke Shutter
26-1242		4.69	HK	Choke Shaft & Lever	27-372	X	0.76	HS	Choke Shutter
26-1247		4.07	HL	Choke Shaft & Lever	27-373	X	0.76	HS	Shutter
26-1251		5.13	HS	Choke Shaft & Lever	27-374	X	0.76	HS	Shutter
26-1258		16.86	HT	Choke Shaft & Lever	27-375	X	0.76	HS	Shutter
26-1260		3.62	HS	Choke Shaft & Lever	27-376	X	0.78	HL	Choke Shutter
26-1262		4.27	HS	Choke Shaft & Lever					
26-1264		4.93	HS	Choke Shaft & Lever					
26-1265		8.02	HK	Choke Shaft & Lever					



PART NO.	QTY CODE	LIST PRICE	USAGE	DESCRIPTION	PART NO.	LIST PRICE	USAGE	DESCRIPTION	
SWIVEL					MIXTURE SCREWS				
28-124		3.05	HL	Connection Wire	43A-2	5.51	HU	Mixture Screw	
28-127		5.38	HL	Connection	43A-9	2.36	HS	Mixture Screw	
28-132		7.90	HL	Connection Wire	43A-19	4.48	HS	Mixture Screw	
28-162		3.45	HU	Cable Pull Swivel	43A-20	3.97	HS	Mixture Screw	
28-164		3.54	HL	Swivel	43A-21	4.65	HS	Mixture Screw	
28-172		2.57	HO	Connection Wire	43A-25	4.14	HU	Mixture Screw	
28-176		1.05	HS	Swivel	43A-28	3.59	HS	Mixture Screw	
28-178		1.08	FO	Connection Wire	43A-34	2.16	HS	Mixture Screw	
28-180		1.08	HS	Swivel	43A-36	3.12		Mixture Screw	
CLIP					43A-43	2.19	HK	Mixture Screw	
29-218	X	0.66	M	Clip	43A-45	4.48	HS	Mixture Screw	
29-220	X	0.66	HK,HS,HU	"E" Ring	43A-60	2.17	HK	Mixture Screw	
29-224	X	0.66	HS,HU	Clip	43A-63	2.25	HK	Mixture Screw	
29-226	X	0.66	HL	Throttle Clip	43A-64	2.04	HK	Adj. Screw	
29-227	X	0.66	TC/WB	"E" Ring	43A-67	2.25	HU	Mixture Screw	
29-239	X	0.66	HS	Clip	43A-70	3.71	HS	Idle Adj. Screw	
29-240	X	0.66	HU	"E" Ring	43A-71	3.71	HS	Main Adj. Screw	
FULCRUM PIN					43A-106	3.24	HU	Mixture Screw	
32-65	X	0.94	HO/TC/WB	Fulcrum Pin	43A-107	3.14	HU	Mixture Screw	
32-72	X	0.51			43A-108	2.01	HS	Mixture Screw	
32-78	X	0.49	HS	Fulcrum Pin	43A-118	2.65	HU	Mixture Screw	
32-79	X	0.49	HS	Fulcrum Pin	43A-120	2.83	HS,HU	Mixture Screw	
32-80	X	0.51	HL	Fulcrum Pin	43A-121	4.31	HS	Mixture Screw	
32-83	X	0.51	HK	Fulcrum Pin	43A-124	3.69	HS	Adjust Screw	
32-506	X	2.39	HL	Fulcrum Pin Assembly	43A-125	1.98	HS	Mixture Screw	
INLET NEEDLE					43A-127	2.39	HT	Idle Mixture Screw	
34-194	X	1.21	HL	Inlet Needle	43A-129	1.78	HU	Idle Adjust Screw	
34-195	X	1.21	HL	Inlet Needle	43A-131	2.83	HT	Main Adjust Screw	
34-202	X	0.86	HL	Inlet Needle	43A-132	3.74	HE	Idle Adjust Screw	
34-216	X	2.37	HS,HU	Inlet Needle	43A-136	2.18	HS	Main Adjust Screw	
34-219	X	2.43	HU	Inlet Needle	43A-143	4.53	HS	Main Adjust Screw	
34-220	X	3.37	HL	Inlet Needle	43A-144	3.54	HU	Idle Adjust Screw	
34-221	X	3.50	TC	Inlet Needle	43A-146	4.53	WB	Idle Adjust Screw	
34-224	X	7.31	HS	Choke Valve Inlet	43A-148	1.94	TC	Idle Adjust Screw	
INLET SEAT					43A-149	3.86	HE	Main Adjust Screw	
36-479		0.47	HL	Inlet Seat (insert)	43A-152	2.65	HS	High Speed Adjust Screw	
36A-27		3.94	HL	Inlet Seat	43A-157	1.46	HU	Main Adjust Screw	
36A-28		4.18	HL	Inlet Seat	43A-159	2.83	HT	Idle Adjust Screw	
36A-30		2.43	HU	Inlet Seat	43A-161	4.17	HT	Adjust Screw	
36A-33		1.85	HS	Inlet Seat	43A-163	8.14	HS	Adjust Screw	
36A-34		4.10	WB	Inlet Seat	43A-164	8.14	HS	Adjust Screw	
36A-36		5.25	TC	Inlet Seat	43A-168	8.14	HS	Adjust Screw	
36A-38		4.15	HL	Inlet Seat	43A-169	8.14	HS	Adjust Screw	
36A-39		4.10	HS	Inlet Seat	43A-172	6.04	HS	Mixture Screw	
					43A-173	6.04	HS	Mixture Screw	
					43A-176	6.04	HS	Mixture Screw	



PART NO.	QTY CODE	LIST PRICE	USAGE	DESCRIPTION	PART NO.	LIST PRICE	USAGE	DESCRIPTION
43A-177		6.04	HS	Mixture Screw	NOZZLE			
43A-178		6.04	HS	Mixture Screw	47A-222	4.64	FO	Main Fuel Nozzle
43A-179		6.04	HS	Mixture Screw	47A-225	4.64	TC	Main Fuel Nozzle
43A-180		6.04	HT	Mixture Screw	47A-272	4.64	HO	Main Fuel Nozzle
43A-181		6.04	HT	Mixture Screw	47A-273	4.64	WB	Main Fuel Nozzle
43A-182		6.04	HO	Mixture Screw	47A-276	4.64	HL	Main Fuel Nozzle
43A-183		6.04	HT	Mixture Screw	47A-277	4.64	TC	Main Fuel Nozzle
43A-187		6.04	HS	Mixture Screw	47A-281	4.64	TC	Main Fuel Nozzle
43A-188		6.04	HS	Mixture Screw	47A-283	4.64	WB	Main Fuel Nozzle
43A-189		8.14	HT	Mixture Screw	47A-284	4.64	FO	Main Fuel Nozzle
43A-190		6.04	HT	Mixture Screw	47A-286	4.64	HL	Main Fuel Nozzle
43A-191		6.04	HT	Mixture Screw	HIGH SPEED JET			
43A-192		6.04	HL	Mixture Screw	49A-161	4.04	HO/FO	Jet (.063)
43A-193		6.04	HL	Mixture Screw	49A-162	4.04	HO/FO	Jet (.057)
43A-194		6.04	HU	Mixture Screw	49A-163	4.04	HO/FO	Jet
43A-203		6.04	HL	Mixture Screw	49A-179	4.04	TC/WB	Jet (.096)
43A-206		6.04	HS	Mixture Screw	49A-181	4.04	TC/WB	Jet (.076)
43A-211		7.03	HS	Mixture Screw	49A-183	4.04	WB/TC	Jet (.088)
43-388		2.91	HL	Mixture Screw	49A-185	4.04	HL	Jet (.039)
43-391		3.96	HL	Mixture Screw	49A-186	4.04	TC/WB	Jet (.070)
43-397		2.87	HL	Main Adjust Needle	49A-187	4.04	HO/FO	Jet (.035)
43-401		2.91	HL	Mixture Screw	49A-199	4.04		Jet (.092)
43-417		2.82	HS	Mixture Screw	49A-200	4.33		Jet (.094)
43-418		2.37	HS	Mixture Screw	49A-203	4.04		Jet (.074)
43-420		2.39	HS	Mixture Screw	49A-214	4.04		Jet (.072)
43-437		2.42	HS	Mixture Screw	49A-217	4.04		Jet (.030)
43-441		2.50	TC	Idle Adjust Screw	49A-221	4.04		Jet (.090)
43-442		2.42	HS	Mixture	49A-440	2.79		
43-455		4.34	HL	Main Adjust Screw	49A-441	4.04		Main Fuel Orifice
43-479		2.31	TC	Idle Adjust Screw	49A-445	4.04		Jet (.0105)
43-486		2.78	HU	Mixture Screw	49A-446	4.04		Jet (.061)
43-489		4.75	HL	Idle Adjust Screw	49A-447	4.04		Jet
43-966		7.46	HL	Mixture Screw	49A-448	4.04		Jet
43-967		6.34	HL	Mixture Screw	49A-450	4.04		Jet (.078)
43-987		6.31	HR	Mixture Screw	49A-451	4.04		Jet (.058)
43-988		5.63	HL	Mixture Screw	49A-452	4.04		Jet
43-995		6.31	HL	Mixture Screw	49A-456	4.04		Jet (.052)
"O" RING - PACKING					49A-458	4.04		Jet
44-267	X	0.69	HL	"O" Ring	49A-459	4.04		Jet (.055)
44-270	X	0.69	HL	"O" Ring	49A-460	4.04		Jet (.060)
44-277	X	0.69	HS	"O" Ring	49A-466	4.04		Jet (.066)
44-296	X	0.69	HS	"O" Ring	49A-473	4.04		Jet (.041)
44-344	X	0.69	HS	"O" Ring	49A-474	4.04		Jet (.050)
44-346	X	0.69	HS	"O" Ring	49A-475	4.04		Jet
44-347	X	0.69	HS	"O" Ring	49A-483	4.38		Jet
44-350	X	0.76	HS	"O" Ring	49A-484	4.04		Jet
					49A-485	4.04		Jet



PART NO.	QTY CODE	LIST PRICE	USAGE	DESCRIPTION	PART NO.	QTY CODE	LIST PRICE	USAGE	DESCRIPTION
49A-488		4.04		Jet	78A-251	X	0.63	HL	Washer
49A-490		4.04		Jet	78A-252	X	0.63	HL	Washer
49A-495		4.04		Jet	78A-253	X	0.63	M	Clip
49A-496		4.04		Jet	78A-256	X	0.63	M	Washer
49B-1		4.04		Jet					
49B-2		4.04		Jet	78A-257	X	0.63	HL	Washer
49B-3		4.04		Jet	78A-263	X	0.63	HL	Lockwasher
49B-4		4.04		Jet					
49B-5		4.04		Jet	78A-265	X	0.63	HL	Washer
49B-10		4.04		Jet	78A-266	X	0.63	HL	Washer
49B-11		4.04		Jet	78A-267	X	0.63	HT	Washer
49B-14		4.04		Jet	78A-280	X	0.63	HS	Throttle Shaft Washer
49B-18		2.97		jet	78A-335	X	0.63	HS	Washer
49B-32		4.04		Jet					
49B-37		4.04		Jet	78A-344	X	0.63	HS	Throttle Shaft Washer
49B-94		2.79		jet	78A-347	X	0.63	HS	Washer
RETAINER					78A-350	X	0.63	HU	Washer
55A-211	X	0.48	HL	Nozzle Check Ball Stop	78A-352	X	0.63	HS	Washer
55A-212	X	0.48	HK,HL,HS	Ring	78A-355	X	0.63	HR	Washer
55A-214	X	0.48	HL	Ch. Ball Stop Nozzle					
55A-216	X	0.48	HK,HU	Stop Check Ball	78A-356	X	0.63	HU	Spacer
55A-222	X	0.49	HS	Disc Nozzle Stop	78A-357	X	0.63	HL	Washer
					78A-358	X	0.63	HU	Washer
55A-223	X	0.49	HK	"E" Ring	PLUGS				
55A-288	X	0.49	HS	Idle Speed Screw Retainer	80-160		1.53	M	Cup Plug
55A-303	X	0.49	HT	Idle Mixture Screw Retainer	80-312		1.53	HO/WB	Plug Screw
55A-304	X	0.49	HT	High Speed Mixture Screw	80-317		1.53	HL	Friction Spring
					80-332		1.53	HL,HU	Cup Ring
55A-305	X	0.49	HS	Adjust Screen Retainer	80-336		1.53	HS	Reducer
55A-306	X	0.49	HT	Retainer					
55A-307	X	0.49	TC	Retainer	80-342		1.53	HS	Plug Screw
BUSHING					80-345		1.53	TC	Plug Screw
60A-231	X	2.44	HL	Bushing	80-352		1.53	HK	Vent Reducer
60A-235	X	2.71	HS	Bushing	80-387		1.53	TC	Plug Screw
					80-392		3.63	TC	Plug
FLOAT BOWL					COVERS				
65-258		3.18	TC	Float Bowl	91A-250		5.36	HL	Diaphragm Cover
65-750		6.21	TC	Float Bowl	91A-251		1.62	HL	Strainer Cover
BODY STRAINER					91A-273		4.22	HS	Cover
67-38		6.55	HL	Inlet Valve Body	91A-274		1.18	HS	Cover
68-283		1.48			91A-275		3.79	HL	Diaphragm
69-165		0.40							
WASHER					91A-282		6.28	HS	Diaphragm Cover
78A-226	X	0.63	M	Washer	91A-295		3.33	HS	Diaphragm Cover
78A-243	X	0.63	M	Washer	91A-300		0.84	HU	Diaphragm Cover
78A-245	X	0.63	M	Washer	91A-302		2.68	HS	Diaphragm Cover
78A-247	X	0.63	M	Lockwasher	91A-303		6.59	HL	Diaphragm Cover
78A-249	Use 78-A251		HL	Washer					
78A-250	X	0.63	HL	Throttle Lever Lockwasher	91A-311		0.84	HU	Diaphragm Cover
					91A-315		7.21	HU	Diaphragm Cover
					91A-344		0.88	HK	Diaphragm Cover
					91A-351		2.50	HL	Cover



ORIGINAL EQUIPMENT CARBURETTORS

PART NO.	QTY CODE	LIST PRICE	USAGE	DESCRIPTION	PART NO.	QTY CODE	LIST PRICE	USAGE	DESCRIPTION
91A-352		2.77	HS	Diaphragm Cover	SLEEVE				
91A-370		2.74	HU	Pump Cover	102-201	X	0.79	HL	Insulator Sleeve
91A-373		1.30	HK	Diaphragm Cover	102-204	X	0.79	HS	Sleeve
91A-467		1.71	HU	Pump Cover	102-208	X	0.79	HK	Throttle Shaft Sleeve
91B-191		3.15	HS	Diaphragm Cover (Stihl)	102-212	X	0.79	HS	Choke Valve Sleeve
91B-208		1.12	HS	Shaft Cover	BODY				
91B-213		5.35	HK	Fuel Pump Cover	141-55		8.69	HL	Fuel Pump Body
91B-218		5.46	HE	Fuel Pump Cover	141-62		8.69	HL	Pump Body
91B-223		0.74	HS	Diaphragm Cover	141-89		8.69	HL	Pump Body
91B-224		2.55	HU	Fuel Pump Cover	INLET LEVER				
91-757		7.89	HL	Diaphragm Cover	155A-23	X	0.66	HL	Inlet Control Lever
91-761		7.50	HS	Cover	155A-26	X	0.66	HS	Inlet Control Lever
91-791		10.61	HS	Pump Cover	155A-27	X	0.66	HL	Inlet Control Lever
91-897		5.55	HS	Diaphragm Cover	155A-28	X	0.66	HU	Inlet Control Lever
91-963		7.74	HT	Fuel Pump Cover	155A-29	X	0.66	HU	Inlet Control Lever
91-967		4.27	HS	Pump Cover	155A-36	X	0.66	HS	Lever
91-968		4.59	HS	Pump Cover	155A-53	X	0.66	HK	Inlet Control Lever
91-970		9.19	HE	Fuel Pump Cover	155A-68		0.66	HU	Throttle Lever
91-974		7.17	HS	Pump Cover	155A-71	X	0.66	HS	Inlet Control Lever
91-976		6.39	HS	Pump Cover	155A-72	X	0.66	HK	Lever
91-981		6.57	HU	Pump Cover	155A-68	X	0.66	HU	Lever
91-984		6.21	HU	Pump Cover	155A-75	X	1.70	HL	Lever
91-985		6.39	HS	Pump Cover	VALVE				
91-992	Use 91-1025				171-647		8.58	HL	Shutter
91-996		7.59	HS	Pump Cover	PLUG				
91-1000		8.95	HR	Pump Cover	179-54	X	0.66	M	Welch Plug
91-1003		8.69	HS	Pump Cover	179-55	X	0.66	HL	Welch Plug
91-1006		7.54	HS	Metering Cover	179-57	X	0.66	HL	Welch Plug
91-1008		7.54	HS	Pump Cover	179-59	X	0.66	HS	Welch Plug
91-1009		7.54	HS	Metering Cover	179-60	X	0.66	HS	Welch Plug
91-1010		7.54	HS	Pump Cover	179-62	X	0.66	HU	Welch Plug
91-1011		7.54	HS	Pump Cover	179-63	X	0.66	TC/WB	Welch Plug
91-1025		6.57	HU	Pump Cover	FUEL FITTING				
STRAINERS					68-282		4.84	HS	Straight Connector
95-170	X	0.73	HL	Strainer Screen	69-195		0.33	HS	Elbow Connector
95-172	X	1.88	OW	Filter Element					
95-174	X	0.79	HL	Fuel Strainer Element					
95-176	X	0.99	HL	Strainer					
95-177	Use 95-233								
95-180	X	0.48	HK,HS,HU	Screen					
95-181	X	0.95	HL	Screen					
95-182	X	1.66	OW	Filter Element					
95-184	Use 95-172								
95-188	X	0.86	HS	Screen					
95-189	X	0.59	HS	Screen					
95-197	X	0.51	HK	Strainer Screen					
95-233	X	0.70	HS	Screen					
95-234	X	0.70	TC	Screen					



PART NO.	QTY CODE	LIST PRICE	USAGE	DESCRIPTION	PART NO.	QTY CODE	LIST PRICE	USAGE	DESCRIPTION
MODULE PLATE					DIAPHRAGMS				
198-305		12.42	HL	Pump Body	237-141	X	2.22		Pump Diahrprgm
198-564	P	12.05	HK	Module	237-143	X	2.08		Pump Diahrprgm
198-565	P	12.05	HK	Module	237-144	X	1.93		Pump Diahrprgm
198-566	P	12.05	HK	Module	237-149	X	5.56	HL	Pump Diaphragm
198-574	P	12.05	HK	Module	237-153	X	2.18		Pump Diaphragm
198-575	P	12.05	HK	Module	237-154	X	2.26		Pump Diaphragm
198-578		12.05	HK	Module	237-155	X	2.25		Inlet Valve Diaphragm
198-579	P	12.05	HK	Module	237-160	X	4.56	HK	
198-580	P	12.05	HL	Module	237-163	X	1.86		Pump Diaphragm
198-582	Use 198-565				237-205	X	2.24		Pump Diaphragm
198-583	P	12.05	HK	Module	237-214	X	2.01		Pump Diaphragm
BALL BEARING					237-215	X	2.01		Pump Diaphragm
206-121	X	0.50	M	Ball	237-216	Use 237-153			
206-123	X	0.50	HS	Speed Screw Retainer	237-217	X	2.01		Pump Diaphragm
206-125	X	0.50	HS	Check Valve Ball	237-600	X	4.42		Metering Diaphragm
206-135	X	0.50	HL	Ball	237-601	X	4.23		Metering Diaphragm
ADAPTOR					237-604	X	4.42		Metering Diaphragm
215-52		2.38	WB	By Pass Tube	237-606	X	5.22		Metering Diaphragm
215-54		2.38	TC	By Pass Tube	237-653	X	4.35		Metering Diaphragm
215-72		2.38	FO	By Pass Tube	237-673	X	4.83		Metering Diaphragm
215-76		2.38	WB	By Pass Tube	237-684	X	4.61		Metering Diaphragm
215-77		2.38	WB	By Pass Tube	237-686	X	4.23		Metering Diaphragm
INLET NEEDLE & SEAT SETS					237-687	X	4.23		Metering Diaphragm
233-647	P	6.82	HL	Needle & Seat	CUP				
233-652	P	6.82	HL	Needle & Seat	318-15	X	0.81	HL	Cup
233-654	P	6.82	HL	Needle & Seat	318-18	X	0.81	HS	Cup
233-660	P	6.82	HL	Needle & Seat	LIMITER CAP				
233-664	Use 233-706				318-32		0.70		Cap
233-665	P	6.82	HL	Needle & Seat	318-33		0.42		Cap
233-669	P	6.82	HL	Needle & Seat	318-34		0.42		Cap
233-672	P	12.60	HL	Needle & Seat	318-35		1.33		Cap
233-677	P	6.82	HL	Needle & Seat	318-39		1.33		Cap
233-692	P	6.82	HL	Needle & Seat	318-40		1.30		Cap
233-697	P	6.82	HL	Needle & Seat	318-43		1.39		Cap
233-703	P	6.82	HL	Needle & Seat	GOVERNOR VALVE				
233-705	P	9.29	HO	Needle & Seat	361-500		6.51	HL	Governor Valve
233-706	P	9.40	HL	Needle & Seat	361-504		6.32	HL,HS	Governor Valve
233-707	P	8.62	HL	Needle & Seat	361-505		6.32	HS	Governor Valve
233-709	P	2.77	HL	Special Inlet Set	361-507		6.32	HS	Governor Valve
233-710	P	8.32	HL	Needle & Seat	361-508		6.32	HL,HS	Governor Valve
233-712	P	3.48	HL	Special Inlet Set	361-510		6.51	HL	Governor Valve
233-715	P	2.77	HL	Special Inlet Set	361-512		6.32	HS	Governor Valve
					361-514		6.32	HS	Governor Valve
					361-516		6.51	HL	Governor Valve
					361-517		6.32	HS	Governor Valve
					361-518		6.32	HS	Governor Valve
					361-525		6.32	HS	Governor Valve
					361-528		6.32	HS	Governor Valve
					361-529		6.32	HS	Governor Valve

LIST				QTY				LIST					
PART NO.	PRICE	USAGE	DESCRIPTION	PART NO.	CODE	PRICE	USAGE	DESCRIPTION	PART NO.	QTY	PRICE	USAGE	DESCRIPTION
361-530	6.32	HS	Governor Valve	363-618		7.27	HS	Check Valve (.56mm)					
361-533	6.32	HS	Governor Valve	363-619		3.40	HS	Check Valve					
361-534	6.32	HS	Governor Valve	363-620		2.98	HU	Check Valve					
361-536	6.32	HS	Governor Valve	363-621		5.97	HT	Check Valve					
361-537	6.32	HS	Governor Valve	363-623		5.63	HS	Check Valve					
361-539	6.51	HT	Governor Valve	363-624		5.63	HS	Check Valve					
361-541	6.51	HL	Governor Valve	363-625		5.79	HS	Check Valve					
361-542	6.32	HS	Governor Valve										
				363-626		5.79	HS	Check Valve					
361-544	6.32	HS	Governor Valve	363-628		5.63	HS	Check Valve					
361-545	6.32	HS	Governor Valve	363-629		5.79	HS	Check Valve					
361-546	6.51	HS	Governor Valve	363-629		5.79	HS	Check Valve					
				363-630		5.97	HT	Check Valve					
				363-631		5.63	HU	Check Valve					
				363-632		5.63	HU	Check Valve					
				363-633		5.97	HU	Check Valve					
				363-640		5.97	HL	Check Valve					
				363-643		5.79	HS	Check Valve					
				363-644		5.97	HL	Idle Shut Off Valve					
				363-649		5.63	HK	Nozzle Check Valve					
				363-655		5.97	HT	Check Valve					
				363-656		5.97	HS	Check Valve					
CHECK VALVE													
363-501	5.55	HL	Check Valve										
363-503	5.83	HL	Check Valve										
363-508	7.16	HR	Check Valve										
363-509	6.30	HS	Check Valve										
363-514	4.91	HS	Check Valve										
363-517	7.63	HS	Governor Valve										
363-518	2.85	HU	Check Valve & Cage										
363-519	2.49	HS	Check Valve										
363-522	1.68												
363-544	7.85	HK	Check Valve										
363-551	5.91		Check Valve										
363-554	3.28	HK	Check Valve										
363-559	4.57	HU	Check Valve										
363-588	3.98	HK	Check Valve										
363-589	3.98	HK	Check Valve										
363-567	5.63	HS	Check Valve (.026)										
363-569	4.70	HL	Check Valve										
363-573	2.72	HK	Check Valve										
363-581	3.40	HS	Check Valve & Jet (.028)										
363-583	3.24	HS	Check Valve										
363-591	5.08	HT	Check Valve										
363-592	2.78	HS	Check Valve										
363-594	4.56	HT,HS	Check Valve										
363-595	4.14	HT,HS	Check Valve										
363-596	4.02	HU	Check Valve										
363-598	2.78	HS	Check Valve										
363-599	5.17	HT,HS	Check Valve										
363-601	3.40	HS	Semi-Fixed Jet (.69mm)										
363-604	3.40	HS	Semi-Fixed Jet (.65mm)										
363-607	3.40	HS	Semi-Fixed Jet (.66mm)										
363-608	3.40	HS	Semi-Fixed Jet (.68mm)										
363-610	3.40	HS	Check Valve (.61mm)										
363-611	3.40	HS	Check Valve (.063m)										
363-616	6.33	HS	Semi Fixed Jet										
CHOKE VALVE ASSEMBLY													
392-501													
392-502				Use 392-502		7.51	HS	Choke Valve Assembly					
392-506		P				7.51	HS	Choke Valve Assembly					
392-508		P				10.43	HU	Choke Valve Assembly					
392-509		P				7.51	HU	Choke Valve Assembly					

PART NO.	LIST PRICE	PART NO.	DESCRIPTION	LIST PRICE
MERCURY MARINE OUTBOARD FLOAT CARBURETTORS		FLOAT CARBURETTOR PARTS		
HO - 2C	106.48	WB		
HO - 4A	106.48	65 - 259	Float Bowl	5.54
HO - 6B	109.20	16 - B178	Bow Nut Gasket (2 req.)	0.1(ea.)
HO - 7A	109.20	80 - 312	Bowl Nut	0.61
FO - 1D	102.93	69 - 169	Fuel Fitting ()	1.50
FO - 3A	114.37	69 - 170	Fuel Fitting (T)	2.53
WB - 103A	141.96	43 - A148	Idle Adj. Screw	0.74
WB - 107A	140.29	24 - B274	Idle Adj. Screw Spring	0.17
WB - 112B	142.79	32 - 65	Fulcrum Pin	0.33
WB - 113B	143.52	34 - 221	Inlet Needle	2.24
WB - 114B	140.18	TC		
WB - 115A	139.92	65 - 750	Float Bowl	17.75
WB - 116A	141.44	69 - 169	Float Bowl Gasket	1.48
WB - 120A	135.20	80 - 345	Bowl Nut (std.)	0.85
WB - 122B	142.72	80 - 392	Bowl Nut (+ fitting)	7.68
WB - 124B	141.44	16 - B180	Bow Nut Gasket (2 req.)	0.14
WB - 125A	142.02	32 - 65	Fulcrum Pin	0.33
WB - 127A	141.34	34 - 221	Inlet Needle	2.24
WB - 131A	142.46	ATCO CYLINDER LAWNMOWER FLOAT CARBURETTOR		
WB - 133A	143.83	FC - 11E	Carburettor (L53121)	70.98
WB - 134A	142.04	24 - C256	Idle speed screw spring	0.15
WB - 135A	142.04	43 - 162	Idle adj. screw	0.74
WB - 139A	139.87	24 - C255	Th. Return spring	1.70
TC - 100A	145.60	34 - 540	Inlet needle	2.17
TC - 101A	143.83	32 - 90	Fulcrum pin	0.15
TC - 102B	143.73	30 - 223	Float	2.78
TC - 103C	144.53	47 - A486	Nozzle	1.85
TC - 104A	141.86	49 - A486	Main jet	1.57
TC - 104B	141.86	80 - 393	Bowl nut	0.32
TC - 105A	141.21	16 - B389	Bowl nut gasket	0.24
TC - 107A	144.56	16 - B388	Bowl gasket	1.01
TC - 108A	136.68			
TC - 110A	141.44			
TC - 111A	143.94			
TC - 111B	143.94			
TC - 112A	139.31			
TC - 119A	142.04			
TC - 121A	141.44			
TC - 124A	142.79			
TC - 125A	142.79			
TC - 130A	140.21			
TC - 131A	140.21			
TC - 134A	141.96			
TC - 135A	141.96			
TC - 137A	137.66			
TC - 138A	139.13			
TC - 139A	139.13			